


Alucon

WALL HUNG CONDENSING BOILERS

INSTALLATION, USER AND SERVICE MANUAL



These instructions are applicable to the following types:

- **Alucon 50**
- **Alucon 70**
- **Alucon 90**
- **Alucon 115**
- **Alucon 125**
- **Alucon 150**



1. MEANING OF THE SYMBOLS AND SAFETY INSTRUCTIONS

1.1 Meaning of The Symbols

WARNINGS:

When reading this manual, pay attention to the parts marked with this symbols



Indicates a situation of possible danger which can lead to serious or fatal injuries if not avoided



Electrical hazards are identified by a lightning icon surrounded by a warning triangle.



Actions that absolutely must not be carry out identified by the figure on left

Keywords indicate the seriousness of the hazard in terms of the consequences of not following the safety instructions.



Important information in cases where there is no risk of injury material losses is identified by the symbol shown on the left.

It is bordered by horizontal lines above and below the text.

- **NOTE** : indicates that material damage may occur.
- **CAUTION** : indicates that injuries may occur.
- **WARNING** : indicates that serious injury may occur.
- **DANGER** : indicates potentially risk to life.

THIS APPLIANCE MUST BE INSTALLED BY A GAS SAFE REGISTERED, AUTHORIZED PERSON. FAILURE TO INSTALL CORRECTLY COULD LEAD TO PROSECUTION.

IF YOU HAVE ANY QUESTION CONTACT THE GASSEROTECHNICAL SERVICE . (technical.service@gassero.com, +90 216 394 09 85)

PLEASE LEAVE THESE INSTRUCTIONS WITH THE COMPLETED INSTALLATION CHECKLIST, AND USER USER MANUAL WITH THE OWNER OR AT THE GAS METER AFTER INSTALLATION OR SERVICING.

THE INSTALLATION AND COMMISSIONING CHECKLIST CAN BE FOUND IN BACK PAGES THE MANUAL.

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

THESE INSTRUCTIONS ARE APPLICABLE TO THE GASSERO BOILER MODELS WRITTEN ON THE FRONT COVER OF MANUAL ONLY AND MUST NOT BE

1.2 General Warnings



After having removed the packaging, check that the material supplied is intact and complete; if this is not the case, contact with GASSERO or dealers.



Ultrabox boilers must be installed by professionally qualified personnel, in conformity with current national and local standards and the instructions in the manual supplied with the product by Gassero



The appliance must be used solely for the purpose for which it has been designed and manufactured

The manufacturer declines all liability for physical injury or damage to animals or objects caused by errors in installation, adjustments, maintenance or improper use of the appliance.



In case of the water leakage, disconnect the boiler from the mains power supply, close the water supply and promptly notify Gassero or other qualified personnel.



Periodically check that the condensate drain is free of blockages.



Periodically check that the hydraulic system operating pressure, in cool conditions, is approx. 2 bar. Otherwise contact the Technical Services department or other professionally qualified personnel.



If the boiler is not used for an extended period, the following operations must be completed:

move the main system switch to "off"

-close the fuel cock and the water cocks on the central heating system

-empty the central heating system if there is the risk of frost.



This manual is an integral part of the boiler and as a consequence must be kept with care. If the manual is damaged or lost, contact with Gassero to supply a new copy.



Maintenance and servicing must be done once a year.

Manually controlled gas valve shall be placed before the boiler.

1.3 Safety Instructions



The boiler must not be used by children or invalid persons without supervision.



Electrical devices or appliances, such as switches, household appliances, etc. must not be used if there is the smell of gas or unburned fuel. In this case :

- ventilate the room by opening doors and windows;

- close the fuel stopcock;
- promptly contact Gassero, your gas supplier or other professionally qualified personnel.



Do not touch the boiler when bare feet or with wet parts of the body.



No service or cleaning operations may be performed without first having disconnected the boiler from the mains power supply, moving the main system switch to "off".



The safety or control devices must not be adjusted without the authorisation and written instructions from the manufacturer of the boiler.



Do not pull, remove or twist the electrical cables coming out of the boiler, even if the appliance is disconnected from the mains power supply.



The ventilation openings in the room where the appliance is installed must not be plugged or reduced in size and must comply with any current standards and law applicable.



Do not switch off the boiler if the outside temperature may decrease below ZERO (risk of freezing).



Do not leave flammable substances in the room where the boiler is installed.



The packaging material must not be dispersed in the environment or left within the reach of children as it is a potential source of hazard. It must be disposed of according to the legislation in force.

Alterations to parts connected to the appliance

Do not carry out any alterations for following parts:

- the boiler
- to the gas, air, water supply pipes and electrical
- to the flue pipe, safety valve and its drain pipe
- to the constructive components which influence the appliance's safe operation.



When tightening or loosening the screw connections, use only adequate tool. The improper use and/or the use of inadequate equipment can cause damages (for example water or gas leakages).



It is strictly forbidden to interfere with any sealed components.

Keywords indicate the seriousness of the hazard in terms of the consequences of not following the safety instructions.

If you smell gas :

If you smell gas follow these safety indications:

- Do not turn on or turn off electrical switches
- Do not smoke
- Do not use the telephone
- Close the mains gas tap
- Open all windows and doors where the gas leakage
- Contact the gas society or a company specialized in installing and servicing heating systems

Precautions to be taken to limit the level of operating noise of the installation;



Observe any unusual noises or operating conditions and make the necessary corrections. Notify responsible individuals for required corrective action or repair.



If frost or corrosion preventative is added to the heating water this can cause changes in the seals and can cause noises to be created during heating.



A heating boiler noise deadening or similar installation can be used to provide noise deadening. Gassero recommends to install the unit on a boiler support foundation 10mm thick.

1.4 Regulation and Standards

The appliance must be installed in accordance with, and comply to, the current: Gas Safety Regulations, IEE Regulations, Building Regulations, Building Standards and any other local requirements.

Directives:

- 2009/142/EC Gas appliance directive
- 92/42/EEC Boiler efficiency
- 2006/95/EC Low voltage
- 2004/108/EC Electromagnetic compatibility

Standards

EN 15502-1:2013 : Gas-fired heating boilers - Part 1: General requirements and tests

EN 15502-2-1:2013 : Gas-fired central heating boilers Part 2-1: Specific standard for type C appliances and type B2, B3 and B5 appliances of a nominal heat input not exceeding 1 000 kW

2. GENERAL

These installation and maintenance instructions apply to following floor standing condensing gas boiler:

- **Alucon 50** • **Alucon 115**
- **Alucon 70** • **Alucon 125**
- **Alucon 90** • **Alucon 150**

The Ultrabox series is suitable for use as a single boiler or as part of a cascade system.

CE LABEL



The appliance complies with the basic requirements of the relevant European directives.

Conformity has been substantiated by the proper documents which, together with the declaration of conformity, are filed with the manufacturer.

2.1 Designed to Use

The boiler may only be used to heat up water for heating systems as standard and/or domestic hot water (DHW) systems with the connection of DHW tank. The boiler can be installed either as a single system or as part of a multiple system (cascade system).

A cascade system enables several boilers of this type to be connected together, where maximum of 16 boilers connected together.

2.2 Description of The Appliance

The **Alucon** is a compact, low pollution, wall-hung condensing boiler with pre-mix burner for CH and DHW (with optional storage). Alucon condensing boilers consist of fully cast aluminum heat exchangers that is suitable to resist the corrosive gases caused from flue gas condensation.

The **Alucon Series** boilers can be combined in a cascade configuration with other heat generators to create modular heating plants made up of boilers connected to the same water circuit and with electronic controllers.

The individual heating units in cascading configuration can be activated, as well as by simple rotation, in such way that when a certain percentage of output is reached by the first unit, the other units start automatically, all with the same load factor communicating via bus.

The main features of the **Alucon** Boilers are:

- full pre-mix microflame fiber coated burner in stainless steel, to guarantee high modulation ratios, combustion stability and extremely low NOx emissions,
- a cast aluminum heat exchanger, considerable resistance corrosion and generously sized exchange surface to optimise energy efficiency and heating output,
- the boiler shall have low resistance to water flow and have no minimum flow rate,
- microprocessor control with self-diagnosis, shown on LED and the display
- frost protection function activated according to the out-side temperature and/or the temperature of the boiler
- fitted for room thermostat in the high and low temperature zones
- outside probe to enable the climate control function-priority settable on the DHW, high or low temperaturecircuit-
- chimney sweep function
- low investment costs for cascade operations (slave - models can be controlled by Master models, without using any display modules in slave units)

2.3 Boiler Room & Ventilation



CAUTION:
Damage to the installation due to frost. Install the heating system in a room which is free from frost.



WARNING:
Fire hazard due to flammable materials or liquids.
Do not store any flammable materials or liquids in the direct vicinity of the boiler.



CAUTION:
Boiler damage due to contaminated combustion air or contaminated air in the boiler room.


Never use the boiler in an environment which contains lots of dust or aggressive chemicals. Such as spray shops, hairdresser's shops, locations where trichloroethylene or hydrogen halides (e.g. contained in aerosols, certain adhesives, solvents or detergents, paints) and other aggressive chemicals are used or stored.


The Alucon condensing boilers must be installed in rooms used exclusively for this purpose, provided with adequately sized ventilation openings, in compliance with any current standards and low applicable.


If the combustion air is taken from outside the room where the boiler is installed, Alucon boilers operates as a room-sealed appliance (type C).

When installing and operating the boilers it is necessary to keep a safe 200 mm distance from combustible materials with combustibility degrees B,C1,C2.

For easily flammable materials with combustibility degree C3 which burn quickly and by themselves also after the ignition source removal the safe distance is doubled it means 400 mm.

 Provide enough clearance to access the safety and control devices and to carry out the servicing operations.

 Check that the index of protection of the boiler is suitable for the characteristics of the room where the appliance is installed.

 If the boilers operate on gas fuel with a higher specific weight than air, the electrical parts must be located at least 500 mm from the floor.


The boilers cannot be installed outside as they are not designed for outdoor operation


2.4 Packaging Label

Product Model : **Alucon J** *Floor Standing Gas Condensing Boilers*


Heat Output : **Y**


Gas Type: I2E,I2H G20 - 20-25 mbar-N.Gas

Product Code :  MASTER
SLAVE

Serial Number : 

Countries of Destination
TURKEY(TR)
20-25 mbar
2H - G20



 All labels are compatible with national and local regulations.





| Y | Z | A | D | C | F | E | H | G |
|------|---|-----|------|------|------|------|------|------|
| 47,8 | 5 | 52 | 7,6 | 49,2 | 7,3 | 47,8 | 51,4 | 8,4 |
| 63,5 | 5 | 97 | 11,6 | 65,6 | 10,7 | 63,4 | 68,5 | 11,6 |
| 86,3 | 5 | 116 | 14,9 | 88,3 | 14,3 | 86,3 | 91 | 15,1 |

2.5 Warning Label

Warnings labels is placed on the boiler and package.


WARNINGS !

- .Read the technical instructions before installing the boiler.
- .Installation and commissioning must be done by authorized qualified technicians.
- .Read the user instructions before lighting the boiler.
- .The boiler may only be installed in a room which complies with the appropriate ventilation requirements and which is separated from living rooms.


2.6 Data Label


ALUCON





Floor Standing Gas Condensing Boilers

| | |
|---|---|
| Model : Alucon J Efficiency Level : ☆☆☆☆ Standard : EN 15502 Production year : NO _x Class : Z Power Supply : ~ 230VAC / 50 Hz Power Consumption : A IP Class : X4D Max. Working Pressure(PMS) : 6 bar Max. Working Temperature : 85°C Flue (appliance) Type : B23,C13,C33,C43,C53,C63,C83 | Nominal Heat Input Q _n Q _n Max. (kW) : C Q _n Min. (kW) : D Nominal Useful Output at (80/60 °C) P _n Max. (kW) : E P _n Min. (kW) : F Nominal Condensing Output at (50/30 °C) P _n Max. (kW) : H P _n Min. (kW) : G |
|---|---|

Serial Number : 

Product Code : 


| | | | |
|--|--------------------------|--------------|----------------|
|  ATTENTION : The boiler is adjusted in the Factory to Gas Pressure of G20 - 20-25 mbar | Countries of Destination | Gas Pressure | Gas Category |
|  Istanbul Endüstri ve Ticaret Serbest Bölgesi (FREE ZONE) , 4. Sok. Parsel 110 34957 , Tuzla, Istanbul, TURKEY www.gassero.com | TURKEY(TR) | 20-25 mbar | I2H,I2E G20 |

.Data label may be changed according to the boiler model.

| J | Y | Z | A | D | C | F | E | H | G |
|-----|-----|---|-----|------|-----|------|-----|-----|------|
| 115 | 112 | 5 | 203 | 14,9 | 112 | 14,3 | 110 | 118 | 15,1 |
| 125 | 124 | 5 | 212 | 19,9 | 124 | 19,2 | 121 | 128 | 22,3 |
| 150 | 143 | 5 | 313 | 19,9 | 143 | 19,2 | 140 | 149 | 22,3 |

3 TECHNICAL FEATURES

3.1 Alucon 60 - 70 - 90 - 115 Series Dimensions



CONNECTIONS :

M : Water outlet connection : 1"

R : Water inlet connection : 1"

G : Gas supply : 1"

F : Flue outlet: Ø100 mm

W : 513mm L : 535 mm H : 770 mm





Ad : Air intake : Ø80

Sc : Condansate drain : Ø25



Counter-flanges and sealing gaskets will be delivered together with the boiler (gas and water connections).

3.2 Alucon 125 - 150 Series Dimensions



CONNECTIONS :

M : Water outlet connection : 1"

R : Water inlet connection : 1"

G : Gas supply : 1"

F : Flue outlet: Ø100 mm

W : 607 mm L : 536 mm H : 770 mm

Ad : Air intake : Ø110

Sc : Condansate drain : Ø25



Counter-flanges and sealing gaskets will be delivered together with the boiler (gas and water connections).



3.5 Dimensions with Concentric Kit





The **concentric kit** is designed for C type chimney and it will be added according to customer request.

The following drawings are presented to show dimension of the boilers in C13, C33 flue applicatons

Alucon 60 - 70 - 90 - 115




Alucon 125 - 150



3.4 Alucon Main Component List


(With Sit Gas Application)



(With EBM Gas Appliance)

KEY

- 1- Fan
- 2- Gas Valve
- 3- Control panel
- 4- Heat Exchanger
- 5- Ionization electrode
- 6- Ignition electrode
- 7- Ignition transformer
- 8- Limit thermostat
- 9- Pressure sensor
- 10- Flow NTC sensor
- 11- Return NTC sensor
- 12- Automatic air vent
- 13- Flue gas sensor
- 14- Flue gas outlet
- 15- Syphon
- 16- Water outlet connection
- 17- Water inlet connection
- 18- Gas inlet
- 19- Air intake
- 20- Venturi
- 21- Syphon switch
- 22- Drain hose and Safety valve



3.5 Technical Data

| Alucon | | 50 | | 70 | | 90 | | 115 | | 125 | | 150 | |
|--|------------------------|-------------------------|------|-------------|------|-------------|------|-------------|-------|-------------|-------|-------------|-------|
| Type Of Flue Installation | | B23,C13,C33,C43,C53,C83 | | | | | | | | | | | |
| Gas category | | I2H,I2E | | | | | | | | | | | |
| Fuel type | | N.G G20-20-25 mbar | | | | | | | | | | | |
| Nominal Heat Input Qn at 80/60 °C | kW | 7,6 | 49,2 | 11,6 | 65,6 | 14,9 | 88,3 | 14,9 | 112,3 | 19,9 | 123,5 | 19,9 | 143,1 |
| Nominal Heat Input Qn at 50/30 °C | kW | 7,8 | 48,8 | 10,7 | 66,3 | 14 | 87,2 | 14 | 113,1 | 20,8 | 118 | 20,8 | 145,1 |
| Nominal Heat Output Pn at 80/60 °C | kW | 7,3 | 47,8 | 10,7 | 63,4 | 14,3 | 86,3 | 14,3 | 109,5 | 19,2 | 120,8 | 19,2 | 139,8 |
| Nominal Heat Output Pn at 50/30 °C | kW | 8,4 | 51,4 | 11,6 | 68,5 | 15,1 | 91 | 15,1 | 118,1 | 22,3 | 128 | 22,3 | 149,1 |
| Working Pressure | bar | 0,8 | 6 | 0,8 | 6 | 0,8 | 6 | 0,8 | 6 | 0,8 | 6 | 0,8 | 6 |
| Boiler Water Capacity | lt | 3,2 | | 3,2 | | 4,6 | | 4,6 | | 6 | | 6 | |
| Maximum Working Temperature | °C | 85 | | 85 | | 85 | | 85 | | 85 | | 85 | |
| Limit Thermostat Shut Down Temperature | °C | 95 | | 95 | | 95 | | 95 | | 95 | | 95 | |
| Efficiency & Emissions | | | | | | | | | | | | | |
| Heating Efficiency 80/60 °C | % | 97,7 | | 97,2 | | 98,4 | | 98,2 | | 98,3 | | 98,2 | |
| Heating Efficiency 50/30 °C | % | 105,9 | | 103,9 | | 105 | | 104,8 | | 104,4 | | 103,2 | |
| Annual Efficiency % (DIN 4702 part 8) | % | 110 | | 110 | | 110 | | 110 | | 110 | | 110 | |
| Useful efficiency at 30% (return 30°C) | % | 108,6 | | 108,4 | | 108,4 | | 108,6 | | 108,5 | | 108,4 | |
| Flue Gas Temperature 50/30 °C | °C | 29,5 - 45,1 | | 30,1 - 52,3 | | 30,2 - 44,8 | | 30,2 - 53,3 | | 30,5 - 44,9 | | 30,5 - 47,1 | |
| Flue Gas Temperature 80/60 °C | °C | 54,7 - 65,6 | | 55,4 - 72,1 | | 56,8 - 61,4 | | 56,8 - 64,9 | | 56,9 - 61,8 | | 56,9 - 70,3 | |
| CO ₂ Emissions | % | 9,2 | 9,3 | 9,2 | 9,6 | 9,3 | 9,4 | 9,4 | 9,4 | 9,5 | 9,5 | 9,5 | 9,5 |
| CO Emissions | ppm | 89 | 44 | 27 | 152 | 27 | 120 | 27 | 156 | 24 | 140 | 24 | 169 |
| NOx Class | | 5 | | | | | | | | | | | |
| Flue gas mass flow rate | g/s | 3 | 22 | 5 | 28 | 7 | 39 | 7 | 51 | 9 | 54 | 9 | 63 |
| Gas Consumption | m³/h | 0,8 | 5,1 | 1,1 | 6,8 | 1,5 | 9,1 | 1,5 | 11,7 | 2,1 | 12,8 | 2,1 | 14,9 |
| Boiler Connections | | | | | | | | | | | | | |
| Boiler Flow Connection | " | 1 | | 1 | | 1 | | 1 | | 1 | | 1 | |
| Boiler Return Connection | " | 1 | | 1 | | 1 | | 1 | | 1 | | 1 | |
| Gas Inlet | " | 1 | | 1 | | 1 | | 1 | | 1 | | 1 | |
| Condensate Drain | Ø | 25 | | 25 | | 25 | | 25 | | 25 | | 25 | |
| Flue Gas Pipe Diameter | Ø | 100 | | 100 | | 100 | | 100 | | 100 | | 100 | |
| Fresh Air Connection | Ø | 80 | | 80 | | 80 | | 80 | | 110 | | 110 | |
| Residual Draught, Fan | Pa | 100 | | 130 | | 170 | | 200 | | 220 | | 330 | |
| Electrical Connections | | | | | | | | | | | | | |
| Power Supply | V/Hz | 230/50 | | 230/50 | | 230/50 | | 230/50 | | 230/50 | | 230/50 | |
| Max. Electrical Consumption | W | 52 | | 97 | | 116 | | 203 | | 212 | | 313 | |
| Stand By Electrical Consumption | W | 3 | | 3 | | 3 | | 3 | | 3 | | 3 | |
| IP Class | IP | X4D | | X4D | | X4D | | X4D | | X4D | | X4D | |
| Boiler Dimensions & Weight | | | | | | | | | | | | | |
| Dimensions WxLxH | mm | 513x535x770 | | 513x535x770 | | 513x535x770 | | 513x535x770 | | 607x536x770 | | 607x536x770 | |
| Weight | kg | 60 | | 60 | | 70 | | 70 | | 82 | | 82 | |

4. INSTRUCTION FOR THE INSTALLER

4.1 Instalation

4.1.1 Packing

The **Alucon** boilers are supplied fully assembled in a strong cardboard box.

After having unpacked the boiler check that it is intact and undamaged.



Keep the packaging material (cardboard box, plastic bags, polyester protection etc.) **out of the reach of children as they can be dangerous.**

GASSERO refuses all liability for injury to persons, animals or damage to property deriving from not having respected the above mentioned recommendations.



The **Alucon** boilers are supplied fully assembled in a strong cardboard box.

After having unpacked the boiler check that it is intact and undamaged.

In the packaging, in addition the boiler, you can also find the following materials;

- Installation, operation and maintenance manual
- Warranty certificate and adhesive labels with bar code
- Outdoor Sensor
- Cascade sensor with cable
- Air Filter (optional)
- Cncentric Kit (optional for C type chimney design)

4.1.2 Transport




Damage to the unit due to it being lifted and carried incorrectly. Do not hold the boiler over the control panel to lift and carry it.

Carefully transport the boiler to the installation place.

we advise you to follow steps for correct transportation;

To lift and carry the boiler, place one hand at the bottom of the boiler and the other hand on its top.



Before mounting the boiler, decide on the ideal position for mounting according to relevant directives and the dimensions of the appliance in mind.

Fix the appliance to a solid wall capable of bearing the weight of the appliance when full of water and fully equipped.



It is forbidden to save inflammable products and materials in the boiler room or close to the boiler,

4.1.3 Mounting


The **Alucon** Boiler must be secured to a solid brick or concrete wall using the wall hanging brackets.

For installation:

- Position the bracket on the wall using correct level to make sure that the holes are perfectly horizontal (1)

- Mark the fastening holes on the wall (1)
- Drill the holes and insert the expansion plugs (2)
- Fasten the bracket to the wall using the screws
- Hook the boiler to the bracket.

For ease of installation we recommend clearances of 0.5 cm at the side so that the unit is easy to open, with a free space of 25 cm under the appliance and 25 cm above the appliance, as the minimum requirement.




4.1.4 Clearances

The gas and water connections are located on the bottom of the boiler whilst the air intake and flue outlet is located on the top of the boiler.

The boiler is supplied as standard with pipe-work tails to allow connections facing downwards.

For installation, servicing and inspection min. 600 mm in front of the boiler is required. If this free space is obtained by opening a door or removing a panel, the boiler may be installed for instance in a closed cupboard.



4.1.5 Water quality and treatment

Treating the supply water allows you to prevent problems and maintain the functionality and efficiency of the generator over time. The purpose of this treatment is to eliminate or significantly reduce problems

In particular, attention must be paid to the following conditions;

Before installing the appliance, thoroughly clean all pipelines and heating elements.

Alucon boiler heat exchanger is made of cast aluminum alloy. The heat exchanger requires proper water conditions to remain efficient and function properly.

- The chemical supplier for use must certify glycol or other treatment chemicals added to the system in multi-metal systems that include cast aluminum boilers.

- Under no circumstances should the hydronic system be flushed while the boiler is attached to the system since the debris or corrosion products may accumulate in the boiler and plug the boiler heat exchanger

- If the piping system attached to this unit will be chemically cleaned, the boiler must be disconnected from the system and a bypass installed so that the chemical cleaning solution does not circulate through the boiler.

- Following chemical cleaning, the system should be thoroughly rinsed to remove cleaning agents prior to reconnecting the boiler to the system.

Properties of water to be used when filling the system;

The following type of water must be used to fill the system:

Proper cleaning and surface preparation must be completed prior to system startup

Initial Start Up of the appliance

| | |
|----------------------------|---------------------------------|
| Total Alkalinity (ppm) | : 100 < CaCO ₃ < 500 |
| Hardness of the filling w. | : from 0,5 to 20 d°H |
| Acidity (pH) | : 7 < pH < 8,5 |
| Suspended Solids | : <10 ppm |
| Chloride | : <125 mg/l |
| Al | : <0,25 MPY |
| Steel | : <3 MPY |
| Cu | : <0,1 MPY |

the following values should be provided during controls and precautions that are performed by an authorized service in yearly service inspections

Working conditions of the appliance

| | |
|----------------------------|---------------------------------|
| Total Alkalinity (ppm) | : 100 < CaCO ₃ < 500 |
| Hardness of the filling w. | : from 0,5 to 20 d°H |
| Acidity (pH) | : 7 < pH < 8,5 |
| Suspended Solids | : <10 ppm |
| Chloride | : <125 mg/l |
| Al | : <0,25 MPY |
| Steel | : <3 MPY |
| Cu | : <0,1 MPY |

4.1.6 Water Side Connection Instructions

The heating capacity of the unit must be previously established by calculating the building's heat requirement according to current regulations. The system must be provided with all the components for correct and regular operation. In particular, provide for all the protection and safety devices prescribed by current regulations for the complete system.



We strongly recommend to install two ball valves under the boiler, so the boiler can be isolated from the heating system when needed.

4.1.7 Expansion Vessel

Ultrabox Series are not supplied with an expansion vessel; therefore its connection must be carried out by the qualified installer.

The capacity of the expansion vessel must be chosen and installed to match the capacity of the central heating system and the static pressure.

We suggest you install the expansion vessel in the return line of the central heating system. It can be combined with the drain valve for servicing.

4.1.8 Safety Valve

Safety valve outlet must be connected to collection pipe to prevent water spurting onto the floor in case of overpressure in the heating circuit. Otherwise, if the discharge valve cuts in and floods the room, the boiler manufacturer cannot be held liable.

4.1.9 Frost Protection

Ultrabox boilers have built-in frost protection, automatically activating the central heating pump when the boiler return water temperature drops below 5°C.


The pump and/or burner will shut down as soon as the return temperature has reached demanded point. The above-mentioned temperatures relates to the temperature measured with the RETURN sensor of the boiler. This Frost Protection provision is for the boiler only and not for the all system.

4.1.10 Dirt Separation

Always install a strainer (water filter) and /or a dirt separator in the return of the boiler in such a way that the boiler water is free of any debris/particles. When using a water filter one should check weekly after installation to determine the strainer cleaning interval.

We advise to mount valves before and after the strainer including an air bleed valve so the strainer can be isolated from the heating circuit for servicing. Clean water is important, blocked heat exchangers do not fall under warranty.

The filter should be installed when replacing boilers in existing systems. The manufacturer declines any liability for damage caused to the boiler by failure to install or inadequate installation of this filter. Before switch on the boiler, water must be circulate at least 2 hours for elimination the impurities from the system through the micro impurity separator. In the end of the operation, safety drain valve must be opened for removing the impurities. It is also possible to use plate heat exchangers according the system characteristics. In any case, micro impurity separators must be used in the system in the boiler. Before installation, carefully wash all the pipes of the system to remove any residuals or impurities that could affect proper operation of the unit. Filter must also be installed on the system return piping to prevent impurities or sludge from the system clogging and damaging the boiler.




4.1.11 Automatic Air Vent

There is an automatic air vent mounted in the boiler to remove air from the water circuit. This automatic air vent is only for eliminate the air in the heat exchanger of the boiler. One or more external automatic air vent(s) and/or air separators should always be installed in the heating system to eliminate air trapped in the heating circuit.

4.1.12 Pressure Drop Curve

Select a pump that is compatible with the hydraulic resistance of the heating unit and system. The graph shows the pressure drop curves of the heating units.


Pressure Drop Curve




Flow Rate - m³/h

4.2 BOILER INSTALLATION SYSTEM EXAMPLES

4.2.1 Single Boiler Installation







Key

- | | |
|--|--|
| 1 - Wallcon condensing boiler | 10 - Heating system(radiator/underfloor) |
| 2 - Room thermostat (QAA55) | 11 - DHW tank pump |
| 3 - Outside probe (QAC34) | 12 - DHW tank sensor (QAZ36) |
| 4 - Condansate discharge | 13 - Hot water |
| 5 - Air seperator | 14 - DHW re-circulation pump |
| 6 - Plate heat exchanger / Low loss header | 15 - DHW tank expansion vessel |
| 7 - Dirt seperator | 16 - DHW tank |
| 8 - Expansion vessel | 17 - Cascade supply sensor (QAD36) |
| 9 - Radiator pump | 18 - Cascade return sensor (QAD36) |

4.2.2 Cascade Installations



Key

- | | |
|--|--|
| 1 - Wallcon condensing boiler | 10 - Heating system(radiator/underfloor) |
| 2 - Room thermostat (QAA55) | 11 - DHW tank pump |
| 3 - Outside probe (QAC34) | 12 - DHW tank sensor (QAZ36) |
| 4 - Condansate discharge | 13 - Hot water |
| 5 - Air seperator | 14 - DHW re-circulation pump |
| 6 - Plate heat exchanger / Low loss header | 15 - DHW tank expansion vessel |
| 7 - Dirt seperator | 16 - DHW tank |
| 8 - Expansion vessel | 17 - Cascade supply sensor (QAD36) |
| 9 - Radiator pump | 18 - Cascade return sensor (QAD36) |

4.3 Adjustment of The Gas Rate


All the instructions written below are for the exclusive use of qualified service technicians or installers. All the boilers are supplied already calibrated and tested.

Adjustments are only be made with special tools.

! **Alucon Series** include two different gas valve control systems.

Adjustments must be done by Gassero authorized services.

4.3.1 Gas Adjustment Points at Dungs




4.3.2 Table of Combastion Values

| Boiler type | Alucon 50 | | Alucon 70 | | Alucon 90 | |
|-----------------------------------|-----------|------|-----------|------|-----------|------|
| | min. | max. | min. | max. | min. | max. |
| CO ₂ % | 9,2 | 9,3 | 9,2 | 9,6 | 9,3 | 9,4 |
| Gas flow rate (m ³ /h) | 0,8 | 5,1 | 1,1 | 6,8 | 1,5 | 9,1 |
| Fan speed (rpm) | 1000 | 5100 | 1250 | 6200 | 1000 | 5600 |

| Boiler type | Alucon 115 | | Alucon 125 | | Alucon 150 | |
|-----------------------------------|------------|------|------------|------|------------|------|
| | min. | max. | min. | max. | min. | max. |
| CO ₂ % | 9,4 | 9,4 | 9,5 | 9,5 | 9,5 | 9,5 |
| Gas flow rate (m ³ /h) | 1,5 | 11,7 | 2,1 | 12,8 | 2,1 | 14,9 |
| Fan speed (rpm) | 1000 | 6100 | 1300 | 6750 | 1300 | 7500 |

4.3.3 Max. Output Setting for Dungs




1 - Connect the gas analyser probe to the sampling test point on the flue.

2 - If the flue gas value in maximum load needs to be adjusted

- Be sure that the boiler is running in full load (Qmax).
- Specify the required flue gas value if necessary (see the technical table) by turning the screw of the main throttle (see below).


3 - For operating in the max. output, press at least 3 seconds to heating mode when the boiler in mode. Controller function stop will appear on the screen. Than press information button, it will indicate the modulation rate (%) on the screen. Adjust the rate to 100 % for max. output setting with using of navigation button. Then press OK. Thus, boiler will operate in maximum power.




! Damage to the boiler by incorrect adjustment of the gas/air-ratio.

To ensure correct operation the values have to be adjusted with extreme care respecting the values indicated in the table.

3 - Connect the pressure gauge connection tube to the positive port of the testing nipple and check the gas supply pressure.




4 - Connect the pressure gauge connection tube to the burner pressure tap and check the burner supply pressure. Burner pressure must be adjust according to the table. Check that the CO₂ values are within the values indicated in the table. Correct the value by turning the adjustment screw (C) in clockwise direction to decrease the value and in an anti-clockwise direction in order to increase the value.




4.3.4 Min. Output Setting for Dungs

1 - For operating in the min. output, press at least 3 seconds to heating mode when the boiler in * mode. Controller function stop will appear on the screen. Than press information button, It will indicate the modulation rate (%) on the screen. Adjust the rate to 0% for min. output setting with using of navigation button. Then press OK. Thus, boiler will operate in minimum power.




2 - Connect the pressure gauge connection tube to the burner pressure tap and check the burner supply pressure. Burner pressure must be adjust according to the table. Check that the CO values are within the values indicated in the table.² Correct the value by turning the adjustment screw (A) in clockwise direction to increase the value and in an anti-clockwise direction in order to decrease the value.




3 - Check the values at the minimum and maximum output.CO₂ Make the required adjustments if necessary. valuesCO₂ have to be adjusted with extreme care respecting the values indicated in the table. When the adjustments have done, close sampling test point in the flue adapter with the cap.

4.3.5 Gas Adjustment Points at Sit



1. Shutt of selenoid valve EV1
2. Offset adjustment screw (Min adjustment)
3. Pilot gas flow restrictor
4. Gas/Air adjustment screw
5. Inlet pressure test point
6. Outlet pressure test point
7. Shutt of selenoid valve EV2

4.3.7 Max. Output Setting for Sit



1 - Connect the gas analyser probe to the sampling test point on the flue.

2 - If the flue gas value in maximum load needs to be adjusted


- Be sure that the boiler is running in full load (Qmax).
- Specify the required flue gas value if necessary (see the technical table) by turning the screw of the main throttle (see below).

3 - For operating in the max. output, press at least 3 seconds to heating mode when the boiler in mode. Controller function stop will appear on the screen. Then press information button, it will indicate the modulation rate (%) on the screen. Adjust the rate to 100 % for max. output setting with using of navigation button. Then press OK. Thus, boiler will operate in maximum power.

4.3.6 Table of Combastion Values


| Boiler type | Alucon 50 | | Alucon 70 | | Alucon 90 | |
|----------------------------------|-----------|------|-----------|------|-----------|------|
| | min. | max. | min. | max. | min. | max. |
| CO ₂ % | 9,2 | 9,3 | 9,2 | 9,6 | 9,3 | 9,4 |
| Gasflow rate (m ³ /h) | 0,8 | 5,1 | 1,1 | 6,8 | 1,5 | 9,1 |
| Fan speed (rpm) | 1000 | 5100 | 1250 | 6200 | 1000 | 5600 |

| Boiler type | Alucon 115 | | Alucon 125 | | Alucon 150 | |
|----------------------------------|------------|------|------------|------|------------|------|
| | min. | max. | min. | max. | min. | max. |
| CO ₂ % | 9,4 | 9,4 | 9,5 | 9,5 | 9,5 | 9,5 |
| Gasflow rate (m ³ /h) | 1,5 | 11,7 | 2,1 | 12,8 | 2,1 | 14,9 |
| Fan speed (rpm) | 1000 | 6100 | 1300 | 6750 | 1300 | 7500 |



Damage to the boiler by incorrect adjustment of the gas/air-ratio.


To ensure correct operation the values have to be adjusted with extreme care respecting the values indicated in the table.



Check that the CO₂ values are within the values indicated in the table. Correct the value by turning the adjustment screw (C) in clockwise direction to decrease the value and in an anti-clockwise direction in order to increase the value.

4.3.8 Min. Output Setting for Sit

1 - For operating in the min. output, press at least 3 seconds to heating mode when the boiler in mode. Controller function stop will appear on the screen. Than press information button, It will indicate the modulation rate (%) on the screen. Adjust the rate to 0% for min. output setting with using of navigation button. Then press OK. Thus, boiler will operate in minimum power.



Check that the CO values are within the values indicated in the table. Correct the value by turning the adjustment screw (A) in clockwise direction to increase the value and in an anti-clockwise direction in order to decrease the value.



Damage to the boiler by incorrect adjustment of the gas/air-ratio.

To ensure correct operation the values have to be adjusted with extreme care respecting the values indicated in the table.

4.4 Gas Conversion Instructions

| | | |
|-------------------|-------|-----|
| Gas Category | I2H | I2E |
| Natural Gas | G20 | G20 |
| Gas Press. (mbar) | 20/25 | 20 |

4.5 Flue Installation Instructions

The flue and the fitting to the flue must be made in compliance with the standards and the legislation in force, as well as with local regulations. The pipes used must be rigid and resistant to temperature, condensate and mechanical stress, and airtight.



Non-insulated flues are potential sources of danger.

The flue assembly shall be so placed or shielded as to prevent ignition or damage to any part of the building. The flue outlet duct and the terminal of the boiler **MUST NOT** be closer than to combustible material.



It is very important to ensure, that products of combustion discharging from the terminal cannot re-enter the building or any other adjacent building. Through ventilators, windows, doors, other sources of natural air infiltration, or forced ventilation / air-conditioning. If this could occur the appliance **MUST** be turned off, and signed as unsafe until corrective action can be taken.



4.5.1 Flue Appliance Type

The table specifies this classification in detail according to CE

| Type | Description |
|------------|---|
| B23 | The combustion air is intaken directly from the room where the boiler is installed. Smoke evacuation duct connected to outside from room where the boiler is installed. |
| C13 | Concentric and closely placed ducts connected to a horizontal terminal for fresh air intake and fume discharge. |
| C33 | Concentric and closely placed ducts connected to a vertical terminal for fresh air intake and fume discharge. |
| C43 | Two connecting ducts and two collecting ?ue ; one for fresh air intake and other one is for fume discharge. |
| C53 | Two ducts connected to the corresponding air intake and fume discharge terminals in different pressure zones. |
| C63 | Air intake and fume discharge ducts and/or terminals are not delivered by the manufacturers and supplied with their own certi?cates. |
| C83 | Ducts to be connected to a terminal and independent or shared ?ue by means an adapter. |

Open flue (B23)

If using an open version, the air supply opening remains open; Only the exhaust (combustion gas) is connected. The boiler then takes in the fresh air required directly from the premises in which it is installed.



| Diameter (mm) | Max. ΔP Pressure (PA) | | | | | |
|---------------|-----------------------|-----|-----|-----|-----|-----|
| | 50 | 70 | 90 | 115 | 125 | 150 |
| 100 | 100 | 130 | 170 | 200 | 220 | 330 |

Room sealed flue (C13, C33, C43, C63)

If using a room sealed version, both the combustion gas exhaust opening and the air supply opening must be connected

| Diameter 100/150 | Alucon Max. Length (HORIZONTAL) | | | | | |
|------------------|---------------------------------|-----|-----|-----|-----|-----|
| | 50 | 70 | 90 | 115 | 125 | 150 |
| | 20m | 20m | 20m | 20m | 18m | 10m |

| Diameter 100/150 | Alucon Max. Length (VERTICAL) | | | | | |
|------------------|-------------------------------|-----|-----|-----|-----|-----|
| | 50 | 70 | 90 | 115 | 125 | 150 |
| | 22m | 22m | 22m | 22m | 20m | 12m |



it is possible to ensure installation conditions of C13, C33 types with **concentric kit and concentric adapter**.

Concentric kit and concentric adapter are optional components

Concentric kit and concentric adapter will be supplied by Gassero according to customer request




To define the maximum final length, you must remove the pipe length in accordance with the reduction table.


| Pipe reductions per element used | | |
|----------------------------------|-----------|-----------|
| Diameter | Elbow 45° | Elbow 90° |
| 100/150 mm | 1 m | 2 m |

Connection in areas of different pressure (C53, C83)

Combustion air supply and combustion gas discharge are possible in various pressure zones, semi-CLV systems. With the exception of coastal areas.



4.6 Condensate Drain



The condensate trap is sized for 25 mm outlet connection pipe.

The condensate line should remain unobstructed, allowing free flow of condensate. If condensate is allowed to freeze in the line or if the line is obstructed in any other manner, condensate can cause potential water damages.



Fit the condensate drain hose and the syphon of the boiler: these are supplied separately.

the siphon should be cleaned at least once bimonthly



the cleaning should be performed according to maintenance description

Condensate Switch

Alucon Boilers are be equipped with Condensate switch as an additional safety to prevent suden overflow for keep the heat

The neutralization box (NB) :

The neutralization box (NB) have to be located in a place protected from frost and atmospheric agent

- Temperature of ambiet: +1 + 40
- It's better to allocated the NB near the boiler in a level ground in order to guarantee the correct position of the material inside it;
- it' must not enter in the NB gas or particles that could damage it (perhaps by inserting a siphon before) ;
- make sure there are no puddles or air bubbles in pipes installation of the NB in the most appropriate to regulate condensate drain (it is recommended to at least 9/10 cm from the top)

Functioning of NB:

The condensate passing through the granulate reduces the acidity by increasing the pH . Acidity is to occur with the litmus test , which is bought in a pharmacy or grocery store

Maintenance of NB:

The pH have to be between 5,5 and 9,5. If the pH is less need to charge the box with the new calcite.

4.7 Electrical Installation

All the wiring is connected to connectors that is fitted in a socket. The connectors can be taken from the sockets on the PCB without loosening the wiring. The connections are placed in the back of the display, and can be reach by removing the front panel of the boiler and the connector protection cover. For operation the boiler needs a power supply of 230VAC 50Hz with earth. Power supply must be removed when you are working on the boiler. Electrical wiring should be done according to national, local or other special standards. Electrical works must be done by a qualified service engineer that is skilled in electrical installation according to the standards.


- 1 - Respect the connection L (Line) - N (Neutral) and earth (ground) connections.
- 2 - Use wires with a cross-section greater than or equal to 1.5 mm², complete with pointed end terminals;
- 3 - Refer to the wiring diagrams in this manual for any operations on the electrical system;
- 4 - Connect the appliance to an effective earth system.
- 5 - Power supply and room thermostat cables must not run near hot surfaces (outlet pipes).



The manufacturer is not liable for any damage due to the failure to earth the appliance and to observe the information provided on the wiring diagrams.


Power supply should be 230 VAC 50 Hz, according to relevant directives tolerance limits are defined (-15% and +10%)


4.7.1 Wiring Diagram





4.7.2 External Probe Installation

The correct positioning of the outside probe is fundamental for the correct operation of the climate control function. The probe must be installed outside of the building being heated, at a height of around 1/2 of the wall facing NORTH or NORTH-WEST and away from flues, doors, windows and areas exposed to direct sunlight.

 The probe should be placed on a smooth section of the wall; in the event of exposed brick walls or uneven walls, a smooth contact area should be used.

 The maximum length of the connection between the outside probe and the control panel is 50 m.

 Any conduits used for the connection cable must be separate from the power cables (230V).

 The connection cable between the probe and control panel must not have junctions; if required, these must be sealed and adequately protected.

Fastening the outside probe to the wall


-Unscrew the cover on the probe protection box, turning it anticlockwise to access the terminal block and the fastening holes

-Trace the fastening points using the protection box as the template

-Remove the box and drill the holes for the expansion plugs

-Fasten the box to the wall using the two plugs supplied- Connect the two wires on the cable to the terminal block, without needing to identify the polarity

-Tighten the nut on the cable gland and close the cover on the protection box.



4.7.3 Outdoor Temperature Control (OTC)


The heating curve generates the flow temperature setpoint, which is used to maintain a certain flow temperature level depending on the prevailing weather conditions. The heating curve can be adjusted in different ways, thus matching the heat output and the room temperature to individual needs. When the heating curve slope is raised, the flow temperature increases as the outside temperature drops. Or, in other words, if the room temperature is not correct at low outside temperatures but correct at higher outside temperatures, the heating curve slope must be readjusted.

Increasing the slope: Raises the flow temperature, especially when the outside temperature is low.

Decreasing the slope: Lowers the flow temperature, especially when the outside temperature is low.

IMPORTANT INFORMATION

i The set heating curve is based on a room temperature setpoint of 20 °C. If this setpoint is changed, the heating curve adapts automatically to the new value.



Parallel displacement of the heating curve is used to change the flow temperature evenly across the entire outside temperature range or, in other words, if the room temperature is always too high or too low, a readjustment must be made with parallel displacement.

Adaption of the heating curve is used by the controller to automatically adapt the heating curve to the prevailing weather conditions. In that case, a readjustment of heating curve slope and parallel displacement is not required. It can only be switched on or off.

The function is activated with parameter, provided a room sensor is used and the compensation variant is weather compensation with room influence. If the required flow temperature is exceeded or is not reached for more than 2 hours, no adaption is made for that day. With pump heating circuits, the boiler temperature is used in place of the flow temperature. Heating curve adaption readjusts the heating curve's slope and the parallel displacement (heat gains).

In Comfort mode (nominal operating level), the function integrates the room temperature control deviation and readjusts at midnight the parameters for calculating the heating curve, depending on the attenuated outside temperature and the learning sensitivity. During boost heating, the deviation of room temperature control is not taken into consideration. When readjusting the heating curve or the heat gains, the sensitivity is automatically set to the maximum.

A certain minimum sensitivity is always maintained. If the attenuated outside temperature is below 4 °C, the heating curve slope is readjusted through the learning process. If the attenuated outside temperature lies between 4 °C and 12 °C, heating curve slope and parallel displacement are readjusted through learning. If the attenuated outside temperature exceeds 12 °C, the learning process is stopped. These basic values apply to a Comfort setpoint of 20 °C, heat gains of 0 K and a heating curve displacement of 0 K.

i To provide this function, following must be observed:


- A room sensor must be connected
- The Room influence setting must be selected between 1 and 99
- No thermostatic radiator valves should be used in the reference room, where the room sensor is located (if installed, such valves must be fully opened and locked in that position)

5. OPERATION

5.1 General

The Ultrabox boilers are fitted with SIEMENS control unit as standart. This controller can be used to control of heating system,with 3 different zones and building automatization.

The boiler controller consists of the following components:



Display choices

- Heating to the Comfort setpoint
- Heating to the Reduced setpoint
- Heating to the frost protection setpoint
- Process running – please wait
- Change battery
- Burner in operation (only oil / gas burner)
- INFO** Info level activated
- PROG** Programming activated
- ECO** ECO function active
Heating system temporarily off
- Holiday function active
- Reference to heating circuit
- Maintenance / special mode
- Error messages

Selection of space heating mode

Press the button to switch between the different operatingThe choice made is indicated by a bar which appears below the symbols.



Automatic operation controls the room temperature according to the time program.

Characteristics of automatic operation:

- Heating mode according to the time program
- Temperature setpoints according to heating program

“Comfort setpoint“

“Reduced setpoint“

- Protective functions active

-Automatic summer / winter changeover (ECO functions)

Continuous operation or

Continuous operation maintains the room temperatureat the selected operating level.

Characteristics of continuous operation:

- Heating mode with no time program
- Protective functions active
- Summer/winter heating limit and automatic

24-hour heating limit (ECO functions)

- During continuous operation with comfort setpoint: not active

- During continuous operation with reduced setpoint: Active

Protective mode

When using Protection, the heating system is off. temperature), provided there is no power failure. But it remains protected against frost(frost protection temperature), provided there is no power failure.

Characteristics of Protection:

Heating off

Temperature according to frost protection

Protective functions active

Automatic summer / winter changeover (ECO functions) and automatic 24-hour heating limit active

:Selecting DHW heating

The button is used to switch DHW heating mode on and off. The choice made is indicated by a bar which appears below the symbols.



On
The DHW is heated according to the selected switching program.

Off
No DHW heating, but the protective function is active.

DHW push

To do this, keep the DHW operating mode button on the operator or room unit depressed for at least 3 seconds.

The DHW push can also be started when:


- The operating mode is "Off"
- Operating mode changeover acts via H1 or centrally
- All heating circuits have assumed the holiday mode

Adjusting the room temperature setpoint

Turn the setting knob to increase or decrease the **Comfort** setpoint ☀

For the **Reduced setpoint** ☾

- Press the OK button
- Select operating page "Heating circuit" and
- Adjust the "Reduced" setpoint



i Each time you make a readjustment, wait at least 2 hours, allowing the room temperature to adapt.

Presence button

If the rooms are not used for a certain period of time, you can press the occupancy button to reduce the room temperature, thus saving heating energy.

When the rooms are occupied again, press again the occupancy button to resume heating operation.

- ☀ Heating to the Comfort setpoint
- ☾ Heating to the Reduced setpoint



i The occupancy button is only active in automatic operation.

The current selection is active until the next switching action according to the heating program occurs.

Displaying information

The Info button is used to display information.



Available information

Certain information lines are hidden, depending on the type of unit, unit configuration and operating state.

Possible displays:

Depending on the type of unit, configuration and operating state, some of the info lines listed below may not appear.

Displays:

- Possible error messages from the error code are listed in the in the manual.


- Possible maintenance alarms from the maintenance code are listed in the manual.

- Possible special mode messages


Other displays:


- Room temperature
- Room temperature minimum
- Room temperature maximum
- Boiler temp
- Outside temperature
- Outside temp min
- Outside temp max
- DHW temp 1
- State heating circuit 1
- State heating circuit 2
- State heating circuit P
- State DHW
- State boiler
- State solar
- State solid fuel boiler
- State buffer storage tank
- Date and time of day
- Telephone customer service

In exceptional cases, display shows one of the following Exceptional cases symbols.

 Error messages

If this symbol appears, a plant fault occurred. In that case, press the Info button to obtain more information.



 Maintenance or special mode

If this symbol appears, a maintenance alarm is delivered or the plant has changed to special mode. In that case, press the Info button to obtain more information.




A list of possible displays is given in the manual.

Reset function

Some errors result in a lock of LMS14/15...


The display shows an code, which will help you to identify the potential cause.

The "RESET" button needs to be pressed after eliminating the reason for the failure, then the boiler will go back to normal operation. Reset button is defined the below symbols.



Manual Control

When manual control is active, the relays are no longer energized and deenergized according to the control state, but are set to a predefined manual operating state depending on their function. The burner relay energized in manual control can be deenergized by the electronic temperature controller (TR).

After manual control has been activated, a change to the basic display must be made. There, the maintenance / special mode symbol  appears.

Press the Info button to switch to info display "Manual mode", where the setpoint can be adjusted.

Chimney sweep function

The chimney sweep function is activated by a short press (maximum 3 seconds) on the chimney sweep button. It produces the operating state required for making flue gas measurements.

SLT test

The SLT test (SLT = safety limit thermostat) is activated by a long press (longer than 3 seconds) on the chimney sweep button. The button must be kept depressed during the entire test. If released, the test will be aborted. The SLT test is shown on the display.



The test must be made by qualified technicians since the boiler temperature will be raised above the maximum limitations.

5.2 Programing

Setting principle

Settings that cannot be made directly with the help of operating elements are made through programming. For this purpose, the individual settings are structured in the form of operating pages and operating lines, thus forming practical groups of settings.




















The following example which shows the setting of the time of day and date shall explain this.

Example "Setting the time of day"


When pressing the ESC button, you go back one step; adjusted values will not be adopted

If any setting is made for 8 minutes, the unit will automatically return to the basic display

Operating lines may be hidden, depending on the type of unit, the configuration and user level


| operation | Display example | Description |
|---|--|---|
| 1   |  | You will see the basic display. If the basic display is not shown, press the ESC button to return to it. Press the OK button. |
| 2   |  | The bottom section of the display shows a number of operating pages. Turn the setting knob until operating page "Time of day and date" appears. To confirm, press the OK button. |
| 3   |  | In the bottom section of the display, the first operating line of operating pages "Time of day and date" appears. Turn the setting knob until operating line "Hours / minutes" appears. To confirm, press the OK button. |
| 4   |  | The display shows the hours flashing. Turn the setting knob until the hours of the time of day are correct. To confirm, press the OK button. |
| 5   |  | The display shows the minutes flashing. Turn the setting knob until the minutes of the time of day are correct. To confirm, press the OK button. |
| 6   |  | The settings are saved, the display stops flashing. You can continue to make other settings, or you press the operating mode button to return to the basic display. |
| 7 |  | Now, you have returned to the basic display. |

Example of menu structure



USER LEVELS


Certain user levels only allow certain user groups to make settings. To reach the required user level, proceed as follows:




To reach the OEM level, enter the relevant code.

Setting structure for "Enduser"

The example given here shows that certain user levels do not allow certain settings to be made. The example shows them highlighted. On the unit, they are hidden.



Setting structure for "Heating engineer"



5.3 Error Codes

The boiler control unit supports a 16-bit error code. Older types of operator units might display 8-bit error codes. If different from the 16-bit error code, the corresponding 8-bit error code is indicated in parentheses.

| Error Code | LPB code | Description of error code |
|------------|----------|--|
| 10 | | Outside temperature, sensor error |
| 20 | | Boiler temperature 1, sensor error |
| 25 | | Boiler temperature, solid fuel, sensor error |
| 26 | | Common flow temperature, sensor error |
| 28 | | Flue gas temperature, sensor error |
| 30 | | Flow temperature 1, sensor error |
| 38 | | Flow temperature, primary controller, sensor error |
| 40 | | Return temperature 1, sensor error |
| 46 | | Cascade return temperature, sensor error |
| 47 | | Common return temperature, sensor error |
| 50 | | DHW temperature 1 sensor error |
| 52 | | DHW temperature 2 sensor error |
| 54 | | Flow temperature DHW, sensor error |
| 57 | | DHW, circulation sensor error |
| 60 | | Room temperature 1, sensor error |
| 65 | | Room temperature 2, sensor error |
| 68 | | Room temperature 3, sensor error |
| 70 | | Storage tank temperature 1 (top), sensor error |
| 71 | | Storage tank temperature 2 (bottom), sensor error |
| 72 | | Storage tank temperature 3 (center), sensor error |
| 73 | | Collector temperature 1, sensor error |
| 78 | | Water pressure, sensor error |
| 82 | | LPB address collision |
| 83 | | BSB wire cross-sectional/no communication |
| 84 | | BSB wire address collision |
| 85 | | BSB RF communication error |
| 91 | | Data overrun in EEPROM |
| 98 | | Extension module 1, error |
| 99 | | Extension module 2, error |
| 100 | | 2 clock time masters |
| 102 | | Clock time master without backup |
| 103 | | Communication error |
| 105 | | Maintenance message |
| 109 | | Supervision boiler temperature |
| 110 | | STB (SLT) lockout |
| 111 | | Temperature limiter safety shutdown |
| 117 | | Water pressure too high |
| 118 | | Water pressure too low |
| 119 | | Water pressure switch has cut out |
| 121 | | Flow temperature heating circuit 1 not reached |
| 122 | | Flow temperature heating circuit 2 not reached |
| 125 | | Maximum boiler temperature exceeded |
| 126 | | DHW charging temperature not reached |
| 127 | | DHW legionella temperature not reached |
| 128 | | Loss of flame during operation |
| 129 | | Wrong air supply |
| 130 | | Flue gas temperature limit exceeded |
| 132 | | Gas pressure switch safety shutdown |
| 133 | | Safety time for establishment of flame exceeded |
| 146 | | Configuration error sensor/controlling elements |
| 151 | | LMS14... error, internally |
| 152 | | Parameterization error |
| 153 | | Unit manually locked |
| 160 | | Fan speed threshold not reached |
| 162 | | Air pressure switch does not close |
| 164 | | Flow/pressure switch, heating circuit error |
| 166 | | Air pressure switch error, does not open |
| 169 | | Sitherm Pro system error |
| 170 | | Error water pressure sensor, primary side |
| 171 | | Alarm contact 1 active |
| 172 | | Alarm contact 2 active |

| | | |
|-----|-----|--|
| 173 | | Alarm contact 3 active |
| 174 | | Alarm contact 4 active |
| 176 | | Water pressure 2 too high |
| 177 | | Water pressure 2 too low |
| 178 | | Temperature limiter heating circuit 1 |
| 179 | | Temperature limiter heating circuit 2 |
| 183 | | Unit in parameterization mode |
| 195 | | Maximum duration of the refill per charging exceeded |
| 196 | | Maximum duration of the refill per week exceeded |
| 209 | | Fault heating circuit |
| 214 | | Monitoring of motor |
| 215 | | Fault fan air diverting valve |
| 216 | | Fault boiler |
| 217 | | Sensor error |
| 218 | | Pressure supervision |
| 241 | | Flow sensor for yield measurement, error |
| 242 | | Return sensor for yield measurement, error |
| 243 | | Swimming pool sensor, error |
| 260 | 217 | Flow temperature 3, sensor error |
| 270 | 215 | Temperature difference, heat exchanger too large |
| 317 | 214 | Mains frequency outside permissible range |
| 320 | 217 | DHW charging temperature, sensor error |
| 321 | 217 | DHW outlet temperature, sensor error |
| 322 | 218 | Water pressure 3 too high |
| 323 | 218 | Water pressure 3 too low |
| 324 | 146 | Input BX, same sensors |
| 325 | 146 | Input BX/extension module, same sensors |
| 326 | 146 | Input BX/mixing group, same sensors |
| 327 | 146 | Extension module, same function |
| 328 | 146 | Mixing group, same function |
| 329 | 146 | Extension module/mixing group, same function |
| 330 | 146 | Sensor input BX1 without function |
| 331 | 146 | Sensor input BX2 without function |
| 332 | 146 | Sensor input BX3 without function |
| 333 | 146 | Sensor input BX4 without function |
| 335 | 146 | Sensor input BX21 without function |
| 336 | 146 | Sensor input BX22 without function |
| 339 | 146 | Collector pump Q5 missing |
| 340 | 146 | Collector pump Q16 missing |
| 341 | 146 | Sensor B6 missing |
| 342 | 146 | Solar charging sensor B31 missing |
| 343 | 146 | Solar integration missing |
| 344 | 146 | Solar controlling element buffer K8 missing |
| 345 | 146 | Solar controlling element swimming pool K18 missing |
| 346 | 146 | Solid fuel boiler pump Q10 missing |
| 347 | 146 | Solid fuel boiler comparative sensor missing |
| 348 | 146 | Solid fuel boiler address error |
| 349 | 146 | Buffer storage tank return valve Y15 missing |
| 350 | 146 | Buffer storage tank address error |
| 351 | 146 | Primary controller/system pump, address error |
| 352 | 146 | Pressureless header, address error |
| 353 | 146 | Sensor B10 missing |
| 371 | 209 | Flow temperature heating circuit 3 |
| 372 | 209 | Temperature limiter heating circuit 3 |
| 373 | 103 | Extension module 3 |
| 374 | 169 | Sitherm Pro calculation |
| 375 | 169 | BV stepper motor |
| 376 | 169 | Drift test limit value |
| 377 | 169 | Drift test prevented |
| 378 | 151 | Internal repetition |
| 382 | 129 | Repetition speed |
| 384 | 151 | Extraneous light |
| 385 | 151 | Mains undervoltage |
| 386 | 129 | Fan speed tolerance |
| 387 | 129 | Air pressure tolerance |
| 388 | 146 | DHW sensor no function |
| 426 | 151 | Feedback flue gas damper |
| 427 | 152 | Configuration flue gas damper |
| 429 | 218 | Dynamic water pressure too high |
| 430 | 218 | Dynamic water pressure too low |
| 431 | 217 | Sensor primary heat exchanger |
| 432 | 151 | Function earth not connected |
| 433 | 216 | Temperature primary heat exchanger too high |

5.4 Maintenance Codes

| Maintenance code | Description of maintenance | Priority |
|------------------|---|----------|
| 1 | Number of burner hours run exceeded | 6 |
| 2 | Number of burner starts exceeded | 6 |
| 3 | Maintenance interval exceeded | 6 |
| 5 | Water pressure heating circuit too low (dropped below lower pressure limit 1) | 9 |
| 10 | Change batteries of outside sensor | 6 |
| 18 | Water pressure 2 heating circuit too low (dropped below lower pressure limit 2) | 9 |
| 10 | Change batteries of outside sensor | 6 |
| 22 | Water pressure 3 heating circuit too low (dropped below lower pressure limit 3) | 9 |
| 25 | Automatic filling of water activated | 3 |

6. MAINTENANCE

6.1 General



Damage to the installation due to insufficient or improper cleaning and maintenance.

Inspect and clean the heating system at least twice a year.

Carry out maintenance as required. Immediately remedy faults. This will avoid further damage to the system!

The boiler should be inspected only by a qualified service technician. In addition, the maintenance and care of the boiler designated and explained on the following pages must be performed to assure maximum boiler efficiency and reliability.

Failure to service and maintain the boiler and system could result in equipment failure.

6.2 Maintenance Procedure

Besides Inspection, maintenance and the replacement of parts we advise to create a log chart belonging to each boiler on which at least the following should be written:

- Serial number of the boiler
- Maintenance date
- Responsible personnel of maintenance.
- Parts and/or settings changed during maintenance.
- Special remarks
- Important points in the future.

During maintenance the following points should be checked and/or parts must be inspected and maintained. Before doing any work on the boiler:

- Switch off the power to the boiler by service switch or pull out plug from wall socket
- Close the gas valve

Customer comments

Comments and notes from the customer should be taken seriously and an effort should be made to find the cause of any problems.

Service history

Faults and working history can be read from boiler interface or with a computer in combination with the software and interface cable of the PCB.

Water leakage

The pressure of the installation must be higher than 0,8 bar, and maximum 6 bar. Find possible leaks in the system and have these fixed.

Flue gas leakage

The flue gas discharge and air intake piping need to be checked for gas leakage. Also check if the piping is properly mounted and not damaged. Inspect the top of the boiler housing for traces of water leakage or traces of water from the air vent, or leaking condensate from the flue gas piping.

Check expansion tank

Expansion tanks provide space for water to move in and out as the heating system water expands due to temperature increase or contracts as the water cools. Tanks may be open, closed or diaphragm or bladder type.

Clean condensate trap

Inspect the condensate drain line and condensate trap.

1. Remove cover beneath the syphon and clean accumulated scale and dirt
2. Replace the cover
3. Fill with fresh water until the water begins to pour out of the drain, then replace the syphon.


Inspect ignition and ionization electrodes

1. Remove front and right side covers of the boiler

1. Remove the ignition and ionization electrodes from side of the heat exchanger
2. Remove any deposits accumulated on the ignition/ionization electrode using sandpaper.


If the electrodes cannot be cleaned satisfactorily, replace with new ones.

3. Replace ignition/ionization electrode, making sure gasket is in good condition and correctly positioned.



Clean Burner and Heat Exchanger

1. Lockout/tag out gas supply to the boiler.
2. Lockout/tag out electrical power to the boiler.
3. Use a proper screwdriver to open the front and both sides covers of the boiler.



4. Remove the wires/cables from the ignition electrode and flame/ionization rod and remove the electrodes

5. Use a proper wrench to remove the nut connecting the gas pipe to the gas control valve

6. Remove the four nuts connecting the blower to the burner hood


7. Remove the four flanged nuts connecting burner hood to Heat exchanger and Carefully lift the burner hood from the heat exchanger.

8. Check the burner gasket and blower gasket whether there is no any damage on the surface of the gaskets, If this is not the case, replace them.

9. Clean the triangular burner using compressed air (approx. 2,5 bar) Check that there is no any deformation on the burner. If this is not the case, replace the burner.

10. Use a vacuum cleaner to clean combustion chamber of the heat exchanger. if necessary, clean with a small stiff bristle, brush or use the special cleaning tool (supplied optional). Compressed air can also be used but care should be taken to ensure disturbed dust etc... does not contaminate the rest of boiler and controls.


11. To re-assemble, perform the above actions that mentioned



The boiler contains ceramic fiber materials. Use care when handling these materials per instructions in the Service Manual. Failure to comply could result in severe personal injury.

Clean fan


If deposits have been building up on the fan blades, carefully clean the blades one by one with a soft brush until the material of the blades is visible again. Work consistently in cleaning the blades, and do not use too much force or else the fan may get out of balance and run irregularly.





Clean the venturi

Use compressed air or a synthetic brush to clean venturi

– Make sure that the silicon hose between gas valve and venturi is clear and in good condition.







GAS BOILER COMMISSIONING CHECKLIST

BOILER SERIAL No: _____ **BOILER MODEL:** _____

CONTROLS To comply with the Building Regulations, each section must have a tick in one or other of the boxes

| | | |
|--|---|--|
| TIME & TEMPERATURE CONTROL TO HEATING | ROOM T/STAT & PROGRAMMER/TIMER <input type="checkbox"/> | PROGRAMMABLE ROOMSTAT <input type="checkbox"/> |
| TIME & TEMPERATURE CONTROL TO HOTWATER | CYLINDER T/STAT & PROGRAMMER/TIMER <input type="checkbox"/> | COMBI BOILER <input type="checkbox"/> |
| HEATING ZONE VALVES | FITTED <input type="checkbox"/> | NOT REQUIRED <input type="checkbox"/> |
| HOTWATER ZONE VALVES | FITTED <input type="checkbox"/> | NOT REQUIRED <input type="checkbox"/> |
| THERMOSTATIC RADIATOR VALVES | FITTED <input type="checkbox"/> | |
| AUTOMATIC BYPASS TO SYSTEM | FITTED <input type="checkbox"/> | NOT REQUIRED <input type="checkbox"/> |

FOR ALL BOILERS CONFIRM THE FOLLOWING

THE SYSTEM HAS BEEN FLUSHED IN ACCORDANCE WITH THE BOILER MANUFACTURER'S INSTRUCTIONS?

THE SYSTEM CLEANER USED _____

THE INHIBITOR USED _____

FOR THE CENTRAL HEATING MODE, MEASURE & RECORD

GAS RATE _____ m³/hr _____ ft³/hr

BURNER OPERATING PRESSURE (IF APPLICABLE) N/A _____ mbar

CENTRAL HEATING FLOW TEMPERATURE _____ °C

CENTRAL HEATING RETURN TEMPERATURE _____ °C

FOR COMBINATION BOILERS ONLY

HAS A WATER SCALE REDUCER BEEN FITTED? YES NO

WHAT TYPE OF SCALE REDUCER HAS BEEN FITTED? _____

FOR THE DOMESTIC HOT WATER MODE, MEASURE & RECORD

GAS RATE _____ m³/hr _____ ft³/hr

MAXIMUM BURNER OPERATING PRESSURE (IF APPLICABLE) N/A _____ mbar

COLD WATER INLET TEMPERATURE _____ °C

HOTWATER OUTLET TEMPERATURE _____ °C

WATER FLOW RATE _____ lts/min

FOR CONDENSING BOILERS ONLY CONFIRM THE FOLLOWING

THE CONDENSATE DRAIN HAS BEEN INSTALLED IN ACCORDANCE WITH THE MANUFACTURER'S INSTRUCTIONS? YES

FOR ALL INSTALLATIONS CONFIRM THE FOLLOWING

THE HEATING AND HOTWATER SYSTEM COMPLIES WITH CURRENT BUILDING REGULATIONS

THE APPLIANCE AND ASSOCIATED EQUIPMENT HAS BEEN INSTALLED AND COMMISSIONED IN ACCORDANCE WITH THE MANUFACTURER'S INSTRUCTIONS

IF REQUIRED BY THE MANUFACTURER, HAVE YOU RECORDED A CO/CO₂ RATIO READING? N/A YES _____ CO/CO₂ RATIO

THE OPERATION OF THE APPLIANCE AND SYSTEM CONTROLS HAVE BEEN DEMONSTRATED TO THE CUSTOMER

THE MANUFACTURER'S LITERATURE HAS BEEN LEFT WITH THE CUSTOMER

COMMISSIONING ENG'S NAME PRINT _____ DATE _____

SIGN _____ 35 _____

SERVICE INTERVAL RECORD

It is recommended that your heating system is serviced regularly and that you complete the appropriate Service Interval Record Below.

Service Provider. Before completing the appropriate Service Interval Record below, please ensure you have carried out the service as described in the boiler manufacturer's instructions. Always use the manufacturer's specified spare part when replacing all c ontrols

SERVICE 1 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 2 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 3 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 4 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 5 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 6 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 7 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 8 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 9 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

SERVICE 10 DATE

ENGINEER NAME _____
COMPANYNAME _____
TELNo. _____
CORGI ID CARD SERIALNo. _____
COMMENTS _____
SIGNATURE _____

Gassero
technology for your comfort

firstcontact@gassero.com

Gassero Isı Teknolojileri Sanayi Limited
Istanbul Endüstri ve Ticaret Serbest Bölgesi (FREE ZONE)
4. Sok. Parsel 110, 34957 Tuzla, Istanbul, Turkey

T: +90 216 394 09 85

www.gassero.com



Gassero reserves the right to change specification without prior notice. Consumers statutory rights are not affected.